Compatible with software versions up to 7		
Error Code	Error	Troubleshooting steps·Items to confirm
90304001	An error occurred in SMART CONSTRUCTION Edge. Shutdown the unit and turn it back on. If this error occurs repeatedly, note the error code and contact us	Please contact support with the time of occurrence (UTC) and error code.
90400001 93204002 93301001	If this error occurs repeatedly, note the error code and contact us. Fail to generate point cloud. The temperature of SMART CONSTRUCTION Edge is outside the allowable range. Shutdown SMART CONSTRUCTION Edge for safety. An error occurred in SMART CONSTRUCTION Edge. Shutdown the unit and turn it back on.	Please contact support with the time of occurrence and error code. Please provide flight data and PPKlog. Daily precautions Immediately after battery replacement, a flight interval of several minutes (3 minutes or more) is required. Periodic Inspection Please free up at least 50 GB of storage space. Please make sure FW is up-to-date Multiple flights Please check if each flight can be handled individually. Place the Edgebox2 in a cool place to lower the temperature and then turn the power on again. When the unit is hot, make sure the cooling fan on the Edgebox2 unit is turning. If the cooling fan does not turn, please get in touch with support. Tablet and Edge2 need to be restarted and reconnected
90200000	If this error occurs repeatedly, note the error code and contact us.	Please contact support with the time of occurrence, error code and period of use Tends to occur when reading flight data It affects the flight immediately after battery replacement. (After battery replacement, it is necessary to wait for at least 3 minutes.) Setup as a fixed station There may be an error in the imported CSV. The format needs to be reviewed. Other Flight data may be incomplete. Re-flight should be considered and an analysis request should be made. (Please share the name and specifications of the SD card you are using.) Please contact support with the time of occurrence and error code. Translated with www.DeepL.com/Translator (free version)
A0200000	An error occurred in SMART CONSTRUCTION Edge. Shutdown the unit and turn it back on. If this error occurs repeatedly, note the error code and contact us.	Please contact support with the time of occurrence (UTC) and error code.
A0201003	An error occurred in SMART CONSTRUCTION Edge. Shutdown the unit and turn it back on. If this error occurs repeatedly, note the error code and contact us.	Please reconfirm the CSV format
A0202001	Could not delete. Please check the job/event list and the send list to see if any processes are running, and perform the following checks before deleting again If there is a process in progress, cancel it. If the result of the process is displayed, clear the list.	Waiting is required until processing is complete.
A0203001	Cannot delete because it is linked or under processing. Please retry after the process.	Waiting is required until processing is complete.
A0203002	Cannot delete because it is linked or under processing. Please retry after the process.	Waiting is required until processing is complete.
A0204001	Cannot delete because it is linked or under processing. Please retry after the process.	Waiting is required until processing is complete.
A0204002	Cannot delete because it is linked or under processing. Please retry after the process.	Waiting is required until processing is complete.
A0204003	Failed to import data. Delete unnecessary data from SMART CONSTRUCTION Edge.	Unnecessary data inside the Edge2 unit needs to be deleted. (sufficient free storage is required).
A0204004	Fail to export data.	Unnecessary data inside the Edge2 unit needs to be deleted.
	There is not enough free space in the USB memory. Cannot delete because it is linked or under processing.	(sufficient free storage is required).
A0204005	Please retry after the process. Cannot delete because it is linked or under processing.	You need to wait until the processing is completed, including the reserved portion.
A0205001	Please retry after the process.	Waiting is required until processing is complete.
A0205002	none	Please wait until the point cloud processing is finished. If you are not processing a point cloud, please reboot the device. (Because the process of deleting failed data is started at the time of startup.)
A0205004	Failed to import data. Delete unnecessary data from SMART CONSTRUCTION Edge.	Unnecessary data inside the Edge2 unit needs to be deleted. (sufficient free storage is required).
A0206001	Detecte unificessary data from shart Construct flow Edge. Removed flight data required for point cloud generation. Please retry from the beginning.	Please reprocess the flight data after importing it.
A0206002	Fail to generate point cloud. No corresponding PPK log for flight data.	Please PPK logs should be checked to see if they have been obtained for more than the flight time If there is a problem with the PPK log, please re-flight.
A0206003	Cannot delete because it is linked or under processing.	Waiting is required until processing is complete.
	Please retry after the process. Cannot delete because it is linked or under processing.	
A0206004	Please retry after the process.	Waiting is required until processing is complete.
A0206006	Cannot delete because it is linked or under processing. Please retry after the process.	Waiting is required until processing is complete.
A0206007	Cannot delete because it is linked or under processing. Please retry after the process.	Waiting is required until processing is complete.
A0206008	Cannot delete because it is linked or under processing.	Waiting is required until processing is complete.
A0206009	Please retry after the process. Wait for it to complete, or select and remove the point cloud data being exported and export it again.	Waiting is required until processing is complete.
	export it again.	PPK logs and flight data should be checked
A020600B	Fail to generate point cloud. No corresponding PPK log for flight data.	If there is a problem with the data, please re-flight.
		If data is OK, please provide PPK logs and flight data to support
A020600C	Fail to export data.	USB flash drive storage must be sufficient

A020C000	none	Unnecessary data inside the Edge2 unit needs to be deleted.
A020C006	Fail to export data.	(sufficient free storage is required).
	Make sure that the USB flash drive is inserted into SMART CONSTRUCTION Edge. Cannot connect to network RTK service.	Reinsert the USB memory stick or try another USB memory stick You may not be able to use (receive) the Ntrip service.
A0300001	Check if Internet communication is stable.	Please change to another Ntrip service to see if you can receive the data.
A0300002	Authentication failed.	Network RKT service is unavailable. First time: Need to check for ID and PASS input errors
A0300002	Addientication falled.	During use: Checking for service suspension and duplicate IDs is required
A0300003	I can't communicate with external radio.	External radio connection needs to be confirmed
	Check the radio settings and retry.	The Edge2 device is not able to provide GNSS positioning.
A0300004	CHICC Desilient of the d	
A0300005	GNSS Positioning failed. Fail to save PPK log.	GNSS reception environment and reception conditions need to be checked. Unnecessary data inside the Edge2 unit needs to be deleted.
A0300005	Delete unnecessary data from SMART CONSTRUCTION Edge.	(sufficient free storage is required).
A0300006	Fail to save PPK log. Distribution has been suspended due to a network error	Please contact support with the time of occurrence (UTC) and error code.
A0400002	Please make sure that you have a stable Internet connection. Fail to transform coordinate system.	Network connection confirmation is required
A0400002 A0400003	Fail to transform coordinate system.	Please check if the EPSG codes match Please check if your drone is compatible with Edge2
A0500001	Fail to PPK process.	Please try to re-flight
40704000	Fail to generate point cloud.	If re-flight does not improve, please provide PPK logs and flight data to support Please try to re-flight
A0701002		If re-flight does not improve, please provide PPK logs and flight data to support
A0701003	Fail to generate point cloud.	When processing multiple flight data in one batch, You need to make sure that they are the same image size.
		There may be insufficient memory.
		It is necessary to take action such as freeing up storage on the Edge2 device.
A0701006	Fail to generate point cloud.	Checkpoints
		If the camera angle in drone was accidentally changed Please try to re-fly the drone.
		Please check if each flight data is successfully processed by itself
		Possible insufficient wrap of flight data
A070100A	Fail to generate point cloud.	Possible insufficient with or night data
A070100A	i ali to generate point ciodu.	Pre-flight check Check for drone airframe and camera malfunctions and remove lens caps prior to flight
		Check for drone anniame and camera manufictions and remove lens caps prior to high
		If re-flight does not improve the problem, please provide PPK log and flight data to support
A070100F	Fail to generate point cloud.	The number of photos in the flight data needs to be checked. Please contact support with the time of occurrence and error code.
A0701010	Fail to generate point cloud.	Please contact support with the time of occurrence (UTC) and error code.
A0702001 A0702002	Fail to generate point cloud. Fail to generate point cloud.	Please contact support with the time of occurrence (UTC) and error code. Please contact support with the time of occurrence (UTC) and error code.
A0702003	Fail to generate point cloud.	Please contact support with the time of occurrence (UTC) and error code.
A0702004	Fail to generate point cloud.	Please contact support with the time of occurrence (UTC) and error code.
A0702005	Fail to generate point cloud.	Please contact support with the time of occurrence (UTC) and error code.
A0702006		
AU/U2UU0	Fail to generate point cloud.	Please contact support with the time of occurrence (UTC) and error code.
A6A01001	Internet communication is not available.	Please check your LTE or wired LAN connection
		Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available.
	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct.	Please check your LTE or wired LAN connection
	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available.
A6A01001	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in.
A6A01001	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint
A6A01001	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard.
A6A01001	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard.
A6A01001	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below.
A6A01002 A6A01003	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard.
A6A01001 A6A01002 A6A01003	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names.
A6A01002 A6A01003	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. none Fail to export data. There is not enough free space in the SD card.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space.
A6A01001 A6A01002 A6A01003	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. none Fail to export data. There is not enough free space in the SD card. Fail to create localized project.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Make sure that the localization CSV file Please check that it follows the format described in the Edge2
A6A01001 A6A01002 A6A01003 B020C003 A020600D A020C005	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Fail to export data. There is not enough free space in the SD card. Fail to create localized project. Check the localization file format. Completed to import the flight data.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space.
A6A01002 A6A01003 B020C003 A020600D	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Fail to export data. There is not enough free space in the SD card. Fail to create localized project. Check the localization file format. Completed to import the flight data. Please confirm if SD card was inserted correctly to SMART CONSTRUCTION Edge.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. UsGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Make sure that the localization CSV file Please check that it follows the format described in the Edge2 manual.
A6A01001 A6A01002 A6A01003 B020C003 A020600D A020C005 A020C007	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Fail to export data. There is not enough free space in the SD card. Fail to create localized project. Check the localization file format. Completed to import the flight data.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Make sure that the localization CSV file Please check that it follows the format described in the Edge2 manual. Please confirm if the SD card is inserted correctly or try formatting it after copy important data to other
A6A01001 A6A01002 A6A01003 B020C003 A020600D A020C005 A020C007	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Pail to export data. There is not enough free space in the SD card. Fail to create localized project. Check the localization file format. Completed to import the flight data. Please confirm if SD card was inserted correctly to SMART CONSTRUCTION Edge. We cannot acquire the appropriate PPK log, because PPK logging time was too short. PPK log must be acquired longer than several minutes. LIFailed to generate localization data.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Make sure that the localization CSV file Please check that it follows the format described in the Edge2 manual. Please confirm if the SD card is inserted correctly or try formatting it after copy important data to other devaice.
A6A01001 A6A01002 A6A01003 B020C003 A020600D A020C005 A020C007	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Fail to export data. There is not enough free space in the SD card. Fail to create localized project. Check the localization file format. Completed to import the flight data. Please confirm if SD card was inserted correctly to SMART CONSTRUCTION Edge. We cannot acquire the appropriate PPK log, because PPK logging time was too short. PPK log must be acquired longer than several minutes.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Make sure that the localization CSV file Please check that it follows the format described in the Edge2 manual. Please confirm if the SD card is inserted correctly or try formatting it after copy important data to other devalce. Please confirm your localization file. Please change the point cloud generation density to low density.
A6A01001 A6A01002 A6A01003 B020C003 A020600D A020C005 A020C007 A0300007 A0400004 A0400005	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Pail to export data. There is not enough free space in the SD card. Fail to create localized project. Check the localization file format. Completed to import the flight data. Please confirm if SD card was inserted correctly to SMART CONSTRUCTION Edge. We cannot acquire the appropriate PPK log, because PPK logging time was too short. PPK log must be acquired longer than several minutes. LIFailed to generate localization data. Point cloud generation failed because the survey area exceeds the upper limit. Depending on the shape of the surveyed area, point cloud generation may fail even if the area is below the upper limit.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Make sure that the localization CSV file Please check that it follows the format described in the Edge2 manual. Please confirm if the SD card is inserted correctly or try formatting it after copy important data to other devaice. Please confirm your localization file. Please change the point cloud generation density to low density. Change the surveyed area to less than the upper area limit.
A6A01001 A6A01002 A6A01003 B020C003 A020600D A020C005 A020C007 A0300007 A0400004	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Authentication failed. Fail to export data. There is not enough free space in the SD card. Fail to create localization file format. Completed to import the flight data. Please confirm if SD card was inserted correctly to SMART CONSTRUCTION Edge. We cannot acquire the appropriate PPK log, because PPK logging time was too short. PPK log must be acquired longer than several minutes. LiFailed to generate localization data. Point cloud generation failed because the survey area exceeds the upper limit. Depending on the shape of the surveyed area, point cloud generation may fail even if	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Make sure that the localization CSV file Please check that it follows the format described in the Edge2 manual. Please confirm if the SD card is inserted correctly or try formatting it after copy important data to other devalce. Please confirm your localization file. Please change the point cloud generation density to low density.
A6A01001 A6A01002 A6A01003 B020C003 A020600D A020C007 A0300007 A0400004 A0400005 A0500002	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Pail to export data. There is not enough free space in the SD card. Fail to create localized project. Check the localization file format. Completed to import the flight data. Please confirm if SD card was inserted correctly to SMART CONSTRUCTION Edge. We cannot acquire the appropriate PPK log, because PPK logging time was too short. PPK log must be acquired longer than several minutes. LiFailed to generate localization data. Point cloud generation failed because the survey area exceeds the upper limit. Depending on the shape of the surveyed area, point cloud generation may fail even if the area is below the upper limit. There's a flight data which was not RTK flight.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Make sure that the localization CSV file Please check that it follows the format described in the Edge2 manual. Please confirm if the SD card is inserted correctly or try formatting it after copy important data to other devaice. Please confirm your localization file. Please change the point cloud generation density to low density. Change the surveyed area to less than the upper area limit. Flight data needs to be verified. For PPK flights, please perform PPK processing. Reboot Edge2 and leave it connected to the network for approximately 1-2 hours, then reboot the
A6A01001 A6A01002 A6A01003 B020C003 A020600D A020C005 A020C007 A0300007 A0400004 A0400005	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Pail to export data. There is not enough free space in the SD card. Fail to create localized project. Check the localization file format. Completed to import the flight data. Please confirm if SD card was inserted correctly to SMART CONSTRUCTION Edge. We cannot acquire the appropriate PPK log, because PPK logging time was too short. PPK log must be acquired longer than several minutes. LIFailed to generate localization data. Point cloud generation failed because the survey area exceeds the upper limit. Depending on the shape of the surveyed area, point cloud generation may fail even if the area is below the upper limit.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Make sure that the localization CSV file Please check that it follows the format described in the Edge2 manual. Please confirm if the SD card is inserted correctly or try formatting it after copy important data to other devaice. Please try to reacquire PPK logs Please confirm your localization file. Please confirm your localization file. Please change the point cloud generation density to low density. Change the surveyed area to less than the upper area limit. Flight data needs to be verified. For PPK flights, please perform PPK processing.
A6A01001 A6A01002 A6A01003 B020C003 A020600D A020C007 A0300007 A0400004 A0400005 A0500002	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Pail to export data. There is not enough free space in the SD card. Fail to create localized project. Check the localization file format. Completed to import the flight data. Please confirm if SD card was inserted correctly to SMART CONSTRUCTION Edge. We cannot acquire the appropriate PPK log, because PPK logging time was too short. PPK log must be acquired longer than several minutes. LiFailed to generate localization data. Point cloud generation failed because the survey area exceeds the upper limit. Depending on the shape of the surveyed area, point cloud generation may fail even if the area is below the upper limit. There's a flight data which was not RTK flight.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Make sure that the localization CSV file Please check that it follows the format described in the Edge2 manual. Please confirm if the SD card is inserted correctly or try formatting it after copy important data to other devaice. Please confirm your localization file. Please change the point cloud generation density to low density. Change the surveyed area to less than the upper area limit. Flight data needs to be verified. For PPK flights, please perform PPK processing. Reboot Edge2 and leave it connected to the network for approximately 1-2 hours, then reboot the Edge2 device. If the problem persists, please contact support with the time of occurrence and error code.
A6A01001 A6A01002 A6A01003 B020C003 A020600D A020C007 A0300007 A0400004 A0400005 A0500002 A3401001 A3401002	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Authentication failed. Pail to export data. There is not enough free space in the SD card. Fail to create localized project. Check the localization file format. Completed to import the flight data. Please confirm if SD card was inserted correctly to SMART CONSTRUCTION Edge. We cannot acquire the appropriate PPK log, because PPK logging time was too short. PPK log must be acquired longer than several minutes. LiFailed to generate localization data. Point cloud generation failed because the survey area exceeds the upper limit. Depending on the shape of the surveyed area, point cloud generation may fail even if the area is below the upper limit. There's a flight data which was not RTK flight. Update cannot complete, because the update file is invalid.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Make sure that the localization CSV file Please check that it follows the format described in the Edge2 manual. Please confirm if the SD card is inserted correctly or try formatting it after copy important data to other devaice. Please try to reacquire PPK logs Please confirm your localization file. Please change the point cloud generation density to low density. Change the surveyed area to less than the upper area limit. Flight data needs to be verified. For PPK flights, please perform PPK processing. Reboot Edge2 and leave it connected to the network for approximately 1-2 hours, then reboot the Edge2 device. If the problem persists, please contact support with the time of occurrence and error code.
A6A01001 A6A01002 A6A01003 B020C003 A020600D A020C005 A020C007 A0400004 A0400005 A0500002 A3401001	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Authentication failed. Pail to export data. There is not enough free space in the SD card. Fail to create localized project. Check the localization file format. Completed to import the flight data. Please confirm if SD card was inserted correctly to SMART CONSTRUCTION Edge. We cannot acquire the appropriate PPK log, because PPK logging time was too short. PPK log must be acquired longer than several minutes. IJFailed to generate localization data. Point cloud generation failed because the survey area exceeds the upper limit. Depending on the shape of the surveyed area, point cloud generation may fail even if the area is below the upper limit. There's a flight data which was not RTK flight. Update cannot complete, because the update file is invalid. Failed to read update status.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Make sure that the localization CSV file Please check that it follows the format described in the Edge2 manual. Please confirm if the SD card is inserted correctly or try formatting it after copy important data to other devaice. Please confirm your localization file. Please change the point cloud generation density to low density. Change the surveyed area to less than the upper area limit. Flight data needs to be verified. For PPK flights, please perform PPK processing. Reboot Edge2 and leave it connected to the network for approximately 1-2 hours, then reboot the Edge2 device. If the problem persists, please contact support with the time of occurrence and error code. Please retry the update using another USB flash drive. confirm the standard of the USB memory stick. Please retry the update using another USB flash drive.
A6A01001 A6A01002 A6A01003 B020C003 A020600D A020C007 A0300007 A0400004 A0400005 A0500002 A3401001 A3401002	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Authentication failed. Fail to export data. There is not enough free space in the SD card. Fail to create localized project. Check the localization file format. Completed to import the flight data. Please confirm if SD card was inserted correctly to SMART CONSTRUCTION Edge. We cannot acquire the appropriate PPK log, because PPK logging time was too short. PPK log must be acquired longer than several minutes. IFailed to generate localization data. Point cloud generation failed because the survey area exceeds the upper limit. Depending on the shape of the surveyed area, point cloud generation may fail even if the area is below the upper limit. There's a flight data which was not RTK flight. Update cannot complete, because the update file is invalid. Failed to read update status. Failed to copy update status. Disconnected network connection.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Make sure that the localization CSV file Please check that it follows the format described in the Edge2 manual. Please confirm if the SD card is inserted correctly or try formatting it after copy important data to other devaice. Please confirm your localization file. Please change the point cloud generation density to low density. Change the surveyed area to less than the upper area limit. Flight data needs to be verified. For PPK flights, please perform PPK processing. Reboot Edge2 and leave it connected to the network for approximately 1-2 hours, then reboot the Edge2 device. If the problem persists, please contact support with the time of occurrence and error code. Please retry the update using another USB flash drive. Check the standard of the USB memory stick. Please retry the update using another USB flash drive. Check the standard of the USB memory stick.
A6A01001 A6A01002 A6A01003 B020C003 A020600D A020C007 A0300007 A0400004 A0400005 A0500002 A3401001 A3401002 A3401003 A3401004 A3401005	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Authentication failed. Pail to export data. There is not enough free space in the SD card. Fail to create localized project. Check the localization file format. Completed to import the flight data. Please confirm if SD card was inserted correctly to SMART CONSTRUCTION Edge. We cannot acquire the appropriate PPK log, because PPK logging time was too short. PPK log must be acquired longer than several minutes. LiFailed to generate localization data. Point cloud generation failed because the survey area exceeds the upper limit. Depending on the shape of the surveyed area, point cloud generation may fail even if the area is below the upper limit. There's a flight data which was not RTK flight. Update cannot complete, because the update file is invalid. Failed to read update status. Failed to copy update status. Disconnected network connection. Confirm the network connection of SMART CONSTRUCTION Edge. Failed updating the firmware.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Make sure that the localization CSV file Please check that it follows the format described in the Edge2 manual. Please confirm if the SD card is inserted correctly or try formatting it after copy important data to other devaice. Please confirm your localization file. Please change the point cloud generation density to low density. Change the surveyed area to less than the upper area limit. Flight data needs to be verified. For PPK flights, please perform PPK processing. Reboot Edge2 and leave it connected to the network for approximately 1-2 hours, then reboot the Edge2 device. If the problem persists, please contact support with the time of occurrence and error code. Please retry the update using another USB flash drive. Confirm the standard of the USB memory stick. Please terry the update using another USB flash drive. Check the standard of the USB memory stick. Please retry the update using another USB flash drive. Check the standard of the USB memory stick. Please check edge2 device in a location with a wired LAN connection or good LTE communication and please wait for the update to complete.
A6A01001 A6A01002 A6A01003 B020C003 A020600D A020C005 A020C007 A0400004 A0400005 A0500002 A3401001 A3401002 A3401003 A3401004	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Authentication failed. Fail to export data. There is not enough free space in the SD card. Fail to create localized project. Check the localization file format. Completed to import the flight data. Please confirm if SD card was inserted correctly to SMART CONSTRUCTION Edge. We cannot acquire the appropriate PPK log, because PPK logging time was too short. PPK log must be acquired longer than several minutes. IJFailed to generate localization data. Point cloud generation failed because the survey area exceeds the upper limit. Depending on the shape of the surveyed area, point cloud generation may fail even if the area is below the upper limit. There's a flight data which was not RTK flight. Update cannot complete, because the update file is invalid. Failed to read update status. Failed to copy update status. Disconnected network connection. Confirm the network connection of SMART CONSTRUCTION Edge.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Make sure that the localization CSV file Please check that it follows the format described in the Edge2 manual. Please confirm if the SD card is inserted correctly or try formatting it after copy important data to other devaice. Please confirm your localization file. Please change the point cloud generation density to low density. Change the surveyed area to less than the upper area limit. Flight data needs to be verified. For PPK flights, please perform PPK processing. Reboot Edge2 and leave it connected to the network for approximately 1-2 hours, then reboot the Edge2 device. If the problem persists, please contact support with the time of occurrence and error code. Please retry the update using another USB flash drive. Check the standard of the USB memory stick. Please retry the update using another USB flash drive. Check the standard of the USB memory stick. Please contact support with the time of occurrence (UTC) and error code. Please contact support with the time of occurrence (UTC) and error code.
A6A01001 A6A01002 A6A01003 B020C003 A020600D A020C007 A0300007 A0400004 A0400005 A0500002 A3401001 A3401002 A3401003 A3401004 A3401005	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Authentication failed. Pail to export data. There is not enough free space in the SD card. Fail to create localized project. Check the localization file format. Completed to import the flight data. Please confirm if SD card was inserted correctly to SMART CONSTRUCTION Edge. We cannot acquire the appropriate PPK log, because PPK logging time was too short. PPK log must be acquired longer than several minutes. LiPailed to generate localization data. Point cloud generation failed because the survey area exceeds the upper limit. Depending on the shape of the surveyed area, point cloud generation may fail even if the area is below the upper limit. There's a flight data which was not RTK flight. Update cannot complete, because the update file is invalid. Failed to read update status. Failed to read update status. Failed to copy update status. Failed to copy update status. Failed to copy update status. It is the same as the existing file name. Please change to a new file name.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Make sure that the localization CSV file Please check that it follows the format described in the Edge2 manual. Please confirm if the SD card is inserted correctly or try formatting it after copy important data to other devaice. Please confirm your localization file. Please change the point cloud generation density to low density. Change the surveyed area to less than the upper area limit. Flight data needs to be verified. For PPK flights, please perform PPK processing. Reboot Edge2 and leave it connected to the network for approximately 1-2 hours, then reboot the Edge2 device. If the problem persists, please contact support with the time of occurrence and error code. Please retry the update using another USB flash drive. Confirm the standard of the USB memory stick. Please terry the update using another USB flash drive. Check the standard of the USB memory stick. Please retry the update using another USB flash drive. Check the standard of the USB memory stick. Please check edge2 device in a location with a wired LAN connection or good LTE communication and please wait for the update to complete.
A6A01001 A6A01002 A6A01003 B020C003 A020600D A020C007 A0400004 A0400005 A0500002 A3401001 A3401002 A3401003 A3401004 A3401005 A0500009	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Authentication failed. Pail to export data. There is not enough free space in the SD card. Fail to create localized project. Check the localization file format. Completed to import the flight data. Please confirm if SD card was inserted correctly to SMART CONSTRUCTION Edge. We cannot acquire the appropriate PPK log, because PPK logging time was too short. PPK log must be acquired longer than several minutes. IF alled to generate localization data. Point cloud generation failed because the survey area exceeds the upper limit. Depending on the shape of the surveyed area, point cloud generation may fail even if the area is below the upper limit. There's a flight data which was not RTK flight. Update cannot complete, because the update file is invalid. Failed to read update status. Disconnected network connection. Confirm the network connection of SMART CONSTRUCTION Edge. Failed updating the firmware. Unknown error occurred. It is the same as the existing file name. Please change to a new file name. Due to the lack of free storage space in SMART CONSTRUCTION Edge, we may fail the	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Make sure that the localization CSV file Please check that it follows the format described in the Edge2 manual. Please confirm if the SD card is inserted correctly or try formatting it after copy important data to other devaice. Please confirm your localization file. Please change the point cloud generation density to low density. Change the surveyed area to less than the upper area limit. Flight data needs to be verified. For PPK flights, please perform PPK processing. Reboot Edge2 and leave it connected to the network for approximately 1-2 hours, then reboot the Edge2 device. If the problem persists, please contact support with the time of occurrence and error code. Please retry the update using another USB flash drive. Check the standard of the USB memory stick. Please retry the update using another USB flash drive. Check the standard of the USB memory stick. Please crott support with the time of occurrence (UTC) and error code. Please contact support with the time of occurrence (UTC) and error code. Please contact support with the time of occurrence (UTC) and error code. Please contact support with the time of occurrence (UTC) and error code.
A6A01001 A6A01002 A6A01003 B020C003 A020600D A020C007 A0300007 A0400004 A0400005 A0500002 A3401001 A3401002 A3401003 A3401004 A3401005 A3401006	Internet communication is not available. If you are using Ethernet, make sure that the cable is connected properly. If you are using LTE, make sure that the settings are correct. An error occurred on the destination server. Note the error code and contact to us. Authentication failed. Authentication failed. Authentication failed. Pail to export data. There is not enough free space in the SD card. Fail to create localized project. Check the localization file format. Completed to import the flight data. Please confirm if SD card was inserted correctly to SMART CONSTRUCTION Edge. We cannot acquire the appropriate PPK log, because PPK logging time was too short. PPK log must be acquired longer than several minutes. LiPailed to generate localization data. Point cloud generation failed because the survey area exceeds the upper limit. Depending on the shape of the surveyed area, point cloud generation may fail even if the area is below the upper limit. There's a flight data which was not RTK flight. Update cannot complete, because the update file is invalid. Failed to read update status. Failed to read update status. Failed to copy update status. Failed to copy update status. Failed to copy update status. It is the same as the existing file name. Please change to a new file name.	Please check your LTE or wired LAN connection Please open a browser on your tablet and check if search is available. You may not be able to log in to the application as an authentication error. Check if you are already logged in. Check if you are using the app in a location with poor internet connection. Checkpoint Users must confirm that they are a user who has purchased the Smar Construction Dashboard. You must confirm that you are the user who purchased the Smar Construction Dashboard. Please try the below. Sign out and sign in from the app of Edge2. USGive each folder on the USB memory stick a unique name for each project, and be careful not to duplicate names. Please delete unnecessary data on the SD card Or, please use an SD card with free space. Nake sure that the localization CSV file Please check that it follows the format described in the Edge2 manual. Please confirm if the SD card is inserted correctly or try formatting it after copy important data to other devaice. Please try to reacquire PPK logs Please confirm your localization file. Please change the point cloud generation density to low density. Change the surveyed area to less than the upper area limit. Flight data needs to be verified. For PPK flights, please perform PPK processing. Reboot Edge2 and leave it connected to the network for approximately 1-2 hours, then reboot the Edge2 device. If the problem persists, please contact support with the time of occurrence and error code. Please retry the update using another USB flash drive. Confirm the standard of the USB memory stick. Please contact support with the time of occurrence (UTC) and error code. Please contact support with the time of occurrence (UTC) and error code.